

Measuring Guide




1 Track to bollard
To make sure you have clearance for your Rasco door.



2 Outside to outside of existing track
To ensure a proper fit with your door.



3 Distance from wall to furthest part of existing track at top of the opening
To ensure a proper seal on the sides, many tracks are farther away from wall at top of opening.



4 Wall to outside edge of roll or distance to back of roll
To ensure a tight seal on the sides.

03/06/26